

## Statement of Memory Volatility

**Models:**

Fluke 1620A, 2626-S, 2626-H

**Product Name:**

DewK Thermo-Hygrometer

**Instrument Description**

Temperature and humidity recorder, consisting of controller and detachable sensors

**Memory Description**

Location	Type	Size	Volatility	Function
Controller	SRAM	128 kilo-bytes	non-volatile	Stores recorded measurement data and statistics, user settings, and the clock time
Sensor	EEPROM	512 bytes	non-volatile	Stores sensor calibration coefficients and calibration date

**Memory Clearing Instructions**

**Recorded measurement data and statistics**

Recorded temperature and humidity measurement data and statistics may be cleared out of non-volatile memory from the front panel of the controller. Once cleared, the data cannot be recovered. Recorded data is completely cleared in two steps:

1. Clear the recorded data using the Data Clear function in the Data Record Menu (refer to the Data Clear section of the User’s Guide).
2. Clear the Daily Statistics using the Stats Clear function in the Daily Stats Menu (refer to the Stats Clear section of the User’s Guide).

**User settings**

User settings may be individually changed (some may require the password) but cannot be cleared.

**Clock time**

The clock time may be changed but cannot be cleared.

**Sensor calibration coefficients and calibration date**

Sensor calibration coefficients and calibration date may be individually changed (requires the password) but cannot be cleared.